

STEP by STEP  
INSTALLATION  
GUIDE



**GAMDIAS**  
**BOREAS | E1**  
410W  
CPU Air Cooler

**GAMDIAS**  
**BOREAS | E1**  
410  
CPU Air Cooler

INTEL ( LGA1366 / 1700 / 1200 / 115X )

**1**  
Turn off the computer before installing

**2**

**3**

**4**

**5**

LGA 1366  
LGA 1700  
LGA 115X / 1200

! Please tighten the screws in a diagonal sequence to spread the tension properly.

**6**

PACKAGE CONTENTS

**A** x1

**B** x1

**C** x1

**D** x1

**E** x1

**F** x4

**G** x1

**B** LGA1366 / 1700 / 1200 / 115X

**C** LGA 2066 / 2011 / 2011-3

2.95mm 3.9mm

**7**

! Make sure cooler firmly touch CPU

**8** If your motherboard has 5V 3-Pin addressable (digital) RGB header, you can customize RGB lighting via motherboard manufacture sync software

! BOREAS E1-410 only support 5V addressable (digital) RGB header

**5**

**6**

**5**

STOCK AMD TOP MOUNTING BRACKET  
REMOVE

**1**

**2**

**1** **4**  
**3** **2**

! Please tighten the screws in a diagonal sequence to spread the tension properly.

**6**

**7**

**8**

If your motherboard has 5V 3-Pin addressable (digital) RGB header, you can customize RGB lighting via motherboard manufacture sync software

! Make sure cooler firmly touch CPU

**7**

**8**

If your motherboard has 5V 3-Pin addressable (digital) RGB header, you can customize RGB lighting via motherboard manufacture sync software

! BOREAS E1-410 only support 5V addressable (digital) RGB header

AURA SYNC	MSI MRGB LIGHT SYNC	ASRock POLYCHROME SYNC	GIGABYTE RGB LIGHT SYNC	BIostar VIVID LED+2

! Make sure cooler firmly touch CPU

**7**

**8**

If your motherboard has 5V 3-Pin addressable (digital) RGB header, you can customize RGB lighting via motherboard manufacture sync software

! BOREAS E1-410 only support 5V addressable (digital) RGB header

AURA SYNC	MSI MRGB LIGHT SYNC	ASRock POLYCHROME SYNC	GIGABYTE RGB LIGHT SYNC	BIostar VIVID LED+2

! Make sure cooler firmly touch CPU

**7**

**8**

If your motherboard has 5V 3-Pin addressable (digital) RGB header, you can customize RGB lighting via motherboard manufacture sync software

! BOREAS E1-410 only support 5V addressable (digital) RGB header

AURA SYNC	MSI MRGB LIGHT SYNC	ASRock POLYCHROME SYNC	GIGABYTE RGB LIGHT SYNC	BIostar VIVID LED+2

! Make sure cooler firmly touch CPU