

QUICK INSTALLATION GUIDE



 **ATLAS | E1**
MID-TOWER PC CASE

 **ATLAS | E1^{WH}**
MID-TOWER PC CASE


TABLE OF CONTENTS

1	Specifications
2	Exploded View & Parts
3	Accessory
4	Side Panel Removal
5	Motherboard Installation
6	PSU Installation
7	3.5" & 2.5" HDD Installation
8	Air Cooling Compatibility
9	Radiator Compatibility
10	I/O Ports
11	I/O Connectors

SPECIFICATIONS

Product Name	ATLAS E1 / ATLAS E1 WH
Case Type	MID Tower
Dimension (L x W x H)	360 x 210 x 480mm 14.2 x 8.3 x 18.9 inch
Chassis Dimension (L x W x H)	358 x 210 x 465 mm 14.1 x 8.3 x 18.3 inch
Motherboard Support	mini-ITX, microATX, ATX
Expansion Slots	7
Material	SPCC, ABS, Tempered Glass
Window	Front, Left
Radiator Support	Top:240 mm Rear:120 mm
Fan Support	Top: 2 x 120mm , 2 x 140mm Rear: 1 x 120mm
Pre-installed Fans	PSU Shroud: 2 x 120mm ARGB Fans Rear: 1 x 120mm ARGB Fan
Pre-installed Control BOX	No
Motherboard Sync	5V 3-Pin Addressable Header
Drive Bays	1 x 3.5"(Chassis Bottom) 2 x 2.5"(SSD Bracket)
Clearance	CPU cooler height limitation: 160mm VGA length limitation: 340mm PSU length limitation: 160mm
I/O Port	USB 3.0 x 2, HD Audio x1, LED Switch x1, Monitor Mode Switch x1

EXPLODED VIEW & PARTS



PARTS


1	Chassis Body	6	IO Port & Screen
2	Tempered Glass Side Panel & Screw	7	120MM ARGB FAN
3	Right Side Panel	8	Rubber Foot
4	Top Dust Filter		
5	Glass Front Panel		

ACCESSORY

FIGURE	PARTS NAME	QTY	USED FOR
	Stand-off 4.75 x 9.5 x 6.5mm	3	Motherboard
	Screw #6 x 6 mm	4	PSU
	Screw #6 x 5 mm	8	HDD
	Screw M3 x 5 mm	25	2.5" HDD/Motherboard/ODD
	CableTie	5	Cable Management

SIDE PANEL REMOVAL

1



English

Remove the side panel

Español

Retire el panel lateral

Deutsch

Seitenblende entfernen

Polski

Usun panel boczny

Français

Retirez le panneau latéral


Svensk

Ta bort sidopanelen

Italiano

Rimuovere il pannello laterale

2



Português

Remova o painel lateral

Русский

Снимите боковую панель

Türk dili

Yan paneli çıkarın

日本語

サイドパネルを取り外します

한국어

사이드 패널 제거


ภาษาไทย

ถอดแผงด้านข้าง

العَرَبِيَّة

فك اللوحة الجانبية

MOTHERBOARD INSTALLATION



English

Lay down the chassis
Install the motherboard in proper location
and secure it with screws

Español

Tumbe el chasis
Instale la placa base en la posición adecuada
y fíjela con los tornillos

Deutsch

Gehäuse flach hinlegen
Motherboard an der richtigen Stelle installieren
und mit Schrauben sichern

Polski

Położ obudowę
Zamontuj płytę główną we właściwym miejscu
I przymocuj za pomocą śrubek

Français

Déposez le châssis
Installez la carte mère dans un emplacement
approprié et fixez-la avec des vis

Svensk

Lägg ner chassiet
Sätt i moderkortet på rätt plats och fäst med
skruvar

Italiano

Poggiare il telaio
Installare la scheda madre nella posizione
corretta e fissarla con viti

Português

Deite o chassi
Instale a placa-mãe no local correto e
prenda-a com parafusos

Русский

Снимите подставку
Установите системную плату в нужном
месте и закрепите винтами

Türk dili

Kasayı yere yatırın
Ana kartı uygun konuma kurun ve vidalarla
sabitleyin

日本語

シャーシーを置きます。
マザーボードを適切な位置に取り付け、
ねじで固定します。

한국어

새시 깔기
마더보드를 올바른 위치에 놓은 뒤
볼트로 고정합니다


ภาษาไทย

วางตัวเครื่องลง
ติดตั้งมาเธอร์บอร์ดในตำแหน่งที่ถูกต้องแล้ว
ยึดด้วยสกรู

العَرَبِيَّة

ضع الهيكل (الشاسيه) على سطح.
رُكِّب اللوحة الأم في المكان السليم وأحکم تثبيتها بالمسامير.

PSU INSTALLATION



English

Place the PSU in proper location

Português

Coloque a PSU no local adequado

Español

Coloque la PSU en la posición adecuada

Русский

Поместите блок питания в нужное место

Deutsch

Netzteil an der richtigen Stelle platzieren

Türk dili

PSU'yu uygun konuma yerleştirin

Polski

Umieścić zasilacz we właściwym miejscu

日本語

電源ユニットを適切な位置に置きます。

Français

Positionnez le bloc d'alimentation électrique dans un emplacement approprié

한국어

PSU를 올바른 위치에 놓습니다

Svensk

Placera PSU:n på rätt plats

ภาษาไทย

วาง PSU ในตำแหน่งที่ถูกต้อง

Italiano


Collocare il PSU in posizione corretta

العربية


ضع وحدة إمداد الطاقة في المكان السليم.

3.5" & 2.5" HDD INSTALLATION

A. 3.5" HDD



B. 2.5" SSD



English

A. 3.5" HDD

Align the HDD into the mounting holes and screw in.

B. 2.5" SSD

Align the SSD into the mounting holes and screw in.

Español

A. HDD de 3,5"

Alinee el HDD en los orificios de montaje y apriete los tornillos.

B. SSD de 2,5"

Alinee el SSD en los orificios de montaje y apriete los tornillos.

Deutsch

A. 3,5-ZOLL-FESTPLATTE

Festplatte in den Montagelöchern ausrichten und einschrauben.

B. 2,5-ZOLL-SSD

SSD in den Montagelöchern ausrichten und einschrauben.

Polski

A. DYSK TWARDY HDD 3,5"

Dopasuj dysk twardy HDD do otworów montażowych i przykręć go.

B. Dysk twardy SSD 2,5"

Dopasuj dysk twardy SSD do otworów montażowych i przykręć go.

Français

A. Disque dur 3,5"

Alignez le disque dur dans les trous de montage et vissez-le.

B. SSD 2,5"

Alignez le SSD dans les trous de montage et vissez-le.

Svensk

A. 3,5" HDD

Sätt i HDD:n i monteringshålen och skruva fast.

B. 2,5" SSD

Sätt i SSD:n i monteringshålen och skruva fast.

Italiano

A. HDD da 3,5"

Allineare l'HDD nei fori di montaggio e avvitarlo.

B. SSD da 2,5"

Allineare l'SSD nei fori di montaggio e avvitarlo.

Português

A. HDD 3.5"

Alinhe o HDD nos orifícios de montagem e aperte-o.

B. HDD 2.5"

Alinhe o SSD nos orifícios de montagem e aperte-o.

Русский

A. Жесткий диск 3,5 дюйма

Установите жесткий диск в монтажные отверстия и закрепите винтами.

Б. Твердотельный накопитель 2,5 дюйма

Вставьте твердотельный накопитель в монтажные отверстия и закрепите винтами.

Türk dili

A. 3,5" SABİT DİSK

Sabit disk bağlantı düzeneği delikleriyle hizalayın ve vidalayın.

B. 2,5" KATI HÂL DİSKİ

Kati hâl diskini bağlantı düzeneği delikleriyle hizalayın ve vidalayın.

日本語

A.3.5インチHDD

HDDを取り付け穴にあて、回し入れます。

B.2.5インチHDD

SSDを取り付け穴にあて、回し入れます。

한국어

A. 3.5" HDD

HDD를 마운팅 홀에 정렬한 뒤 볼트로 고정합니다.

B. 2.5" HDD

SSD를 마운팅 홀에 정렬한 뒤 볼트로 고정합니다.

ภาษาไทย

A. ฮาร์ดดิสก์ไดรฟ์ขนาด 3.5 นิ้ว

จัดเรียงฮาร์ดดิสก์ไดรฟ์ลงในช่องสำหรับประกอบแล้วขันสกรูยึดให้แน่น

B. โซลิดสเตตไดรฟ์ขนาด 2.5

จัดเรียงโซลิดสเตตไดรฟ์ลงในช่องสำหรับประกอบแล้วขันสกรูยึดให้แน่น

العربية


أ- محرك الأقراص الثابتة 3.5 بوصة

قم بمحاذاة المحرك في فتحات التثبيت وثّبه.

ب- محرك الأقراص ذو الحالة الثابتة 2.5 بوصة

قم بمحاذاة المحرك في فتحات التثبيت وثّبه.

AIR COOLING COMPATIBILITY



English

Top	2 x 120mm or 2 x 140mm
PSU Shroud	2 x 120mm
Rear	1 x 120mm

Svensk

Ovansida	2 x 120mm eller 2 x 140mm
PSU-skydd	2 x 120mm
Baksida	1 x 120mm

日本語

上部	120 mm x 2 または 140 mm x 2
PSUカバー	120 mm x 2
後部	120 mm x 1

Español

Superior	2 x 120mm o 2 x 140mm
Cubierta de PSU	2 x 120mm
Trasero	1 x 120mm

Italiano

Parte superiore	2 x 120mm o 2 x 140mm
Copertura PSU	2 x 120mm
Parte posteriore	1 x 120mm

한국어

상단	120 mm x 2 or 140 mm x 2
PSU 커버	120 mm x 2
후면	120 mm x 1

Deutsch

Oben	2 x 120mm oder 2 x 140mm
PSU-Abdeckung	2 x 120mm
Hinten	1 x 120mm

Português

Superior	2 x 120mm ou 2 x 140mm
Cobertura da PSU	2 x 120mm
Traseiro	1 x 120mm

ภาษาไทย

ด้านบน	120 มม. x 2 หรือ 140 มม. x 2
ฝาครอบ PSU	120 มม. x 2
ด้านหลัง	120 มม. x 1

Polski

Góra	2 x 120mm lub 2 x 140mm
Osłona PSU	2 x 120mm
Tył	1 x 120mm

Русский

Верхний	120 мм, 2 шт. или 140 мм, 2 шт.
Кожух БП	120 мм, 2 шт.
Задний	120 мм, 1 шт.

العَرَبِيَّة

أمامي 120 مم x 2 أو 140 مم x 2
غطاء وحدة الإمداد بالطاقة (PSU) 120 مم x 2
خلفي 120 مم x 1


Français

Haut	2 x 120mm ou 2 x 140mm
Cache PSU	2 x 120mm
Arrière	1 x 120mm

Türk dili

Üst	2 tane 120 mm veya 2 tane 140 mm
PSU Kapağı	2 tane 120 mm
Arka	1 tane 120 mm

RADIATOR COMPATIBILITY



English

Top 240mm
Rear 120mm

Svensk

Ovansida 240mm
Baksida 120mm

日本語

上部 240 mm
後部 120 mm

Español

Superior 240mm
Trasero 120mm

Italiano

Parte superiore 240mm
Parte posteriore 120mm

한국어

상단 240 mm
후면 120 mm

Deutsch

Oben 240mm
Hinten 120mm

Português

Superior 240mm
Traseiro 120mm

ภาษาไทย

ด้านบน 240 มม.
ด้านหลัง 120 มม.

Polski

Góra 240mm
Tył 120mm

Русский

Верхний 240 мм
Задний 120 мм

العَرَبِيَّة

أمامي 240 مم
خلفي 120 مم


Français

Haut 240mm
Arrière 120mm

Türk dili

Üst 240 mm
Arka 120 mm


I/O PORTS




1	Power Button	4	USB 3.0
2	Screen Control & Reset	5	USB 3.0
3	Integrated Audio (Headphone & Microphone)		

I/O CONNECTORS


USB 3.0




USB 2.0



HD AUDIO




POWER SW



HDD LED




POWER LED+



POWER LED-



ARGB



English

See your motherboard's manual for front panel header locations and pin-outs.

Português

Veja o manual da sua placa-mãe para localizar os locais e os compartimentos do painel frontal.

Español

Consulte en el manual de la placa base las ubicaciones de los cabezales del panel frontal y las salidas de conectores.

Deutsch

Positionen und Pinbelegungen der Stiftheuten an der Frontblende finden Sie in der Motherboard-Anleitung.

Polski

Zapoznaj się z instrukcją do płyty głównej w celu uzyskania informacji o położeniu gniazda panelu przedniego i pinów.

Français

Consultez le manuel de votre carte mère pour les emplacements des embases du panneau avant et les sorties pi.

Svensk

Se bruksanvisningen för moderkortet för huvud och pi-utgångar på framsidan.

Italiano

Vedere il manuale della scheda madre per le posizioni e le piedinature del connettore del pannello anteriore.

Русский

Схема расположения колодок передней панели и выводов представлена в руководстве к системной плате.

Türk dili

Ön panel bağlantı konumları ve Pi çıkışları için ana kartınızın kılavuzuna bakın.

日本語

フロントパネルヘッダーの位置と操作はマザーボードマニュアルを参照

한국어

프론트 패널 헤더 위치와 pi 아아웃은 마더보드의 매뉴얼을 참조하십시오.


ภาษาไทย

อ่านคู่มือมาเธอร์บอร์ดของคุณเพื่อรับทราบตำแหน่งส่วนหัวแผงด้านหน้าและ Pi-out


العَرَبِيَّة

راجع دليل اللوحة الأم لتحديد مواضع رأس اللوحة والدبابيس.


DISPLAY CONNECTION



Attached switch



Motherboard



SOFTWARE DOWNLOAD: ZEUS CAST



PC COMPONENTS FURNITURE GAMING GEAR SOFTWARE AURA SERVICE

  English 

	Radiator Support	Top: 240mm / Rear: 120mm
	Fan Support	Top: 2 x 120mm · 2 x 140 mm Rear: 1 x 120mm
	Pre-installed Fans	PSU Shroud: 2 x 120mm ARGB Fans Rear: 1 x 120mm ARGB Fan
	Drive Bays	1 x 3.5"(Chassis Bottom) 2 x 2.5"(SSD Bracket)
	I/O Port	USB 3.0 x 2, HD Audio x1, LED Switch x1, Monitor Mode Switch x1
	Clearance	CPU cooler height limitation: 160mm VGA length limitation: 340mm PSU length limitation: 160mm
	Dimension (L x W x H)	360 x 210 x 490mm
	Net Weight	6.3 kg / 13.9 lb

Downloads

USER MANUAL

SOFTWARE APP 

COMMUNITY

News
Our Discord

COMPANY

About Us
Privacy Policy
Warranty

SUPPORT

Downloads
Contact Us
FAQ
Where To Buy
Legacy Products

FOLLOW GAMDIAS


    




STEP

- 1 Visit Gamdias Official Website
- 2 Visit ATLAS M1 Product Page
- 3 Stroll down the Page to Find the Download Resource
- 4 Download Zeus Cast Package


MODE VARIATION AND INSTRUCTION




TEMP BUTTON




1 CPU mode




2 GPU mode



3 AMB mode




4 Light-off



Press the button to switch ATLAS display information between 4 different modes

Note: Zeus Cast is still running in the background in Light-off mode

SOFTWARE INSTRUCTION




GENERAL SETTINGS

1	Temperature Display
2	Auto-Run
3	Minimize to system tray at close
4	Language

Note: The Temperature Display switch function can only be changed by Zeus Cast

SOFTWARE INSTRUCTION



ATLAS DIGITAL DISPLAY

- | | |
|---|-------------------|
| 1 | Display Mode |
| 2 | Temperature Alarm |

Note: The Temperature Display switch function can only be changed by Zeus Cast



GAMDIAS

GAMING ART IN MOTION