

STEP BY STEP INSTALLATION GUIDE




GAMDIAS

AEOLUS | M2
1201

Case & Radiator Fan

Package Contents

A




X1

B



X4

**English**

- ◆ Make sure that your system is turned off and unplugged.

Français

- ◆ Assurez-vous que le système est éteint et débranché.

Русский

- ◆ Убедитесь, что система выключена и отключена от электросети.

Deutsch

- ◆ Stellen Sie sicher, dass Ihr System ausgeschaltet und alle Stromkabel gezogen sind.

繁體中文

- ◆ 請確定系統已關閉且已斷電。

简体中文

- ◆ 请确保系统已关闭，并已拔出插头。

Español

- ◆ Asegúrese de que el sistema está apagado y desenchufado.

Italiano

- ◆ verificare che il sistema sia spento e scollegato.

Português


- ◆ Certifique-se que o seu sistema está desligado e sem corrente eléctrica.

Türk dili

- ◆ Sisteminizin kapalı olduğundan ve fişinin takılı olmadığından emin olun.

日本語


- ◆ システムがオフになっており、プラグを抜いていることを確認してください。



03

If your motherboard has 5V 3-Pin addressable (digital) LED header, you can customize RGB lighting via motherboard manufacture sync software


A




ADD_HEADER	JRAINBOW	ADDR_LED	V D G	V D G

04

Two methods to control build-in RGB Lighting
Method 1. Use included button




If the motherboard RGB sync function is used, the button function will be automatically disabled.




05

Two methods to control build-in RGB Lighting
Method 2. If your case has “RESET SW”, you can use case button to change lighting modes

1





2





If the motherboard RGB sync function is used, the button function will be automatically disabled.






07

The design of male and female Molex to deal with insufficient socket







GAMDIAS

GAMING ART IN MOTION