# STEP by STEP INSTALLATION GUIDE


GAMDIAS
AEOLUS | M2 1204R
Case & Radiator Fan WH

GAMDIAS
AEOLUS | M2 1204R
Case & Radiator Fan

# Package Contents

A  X4

B 

X1

C 

X1

D 

X1

E  X1

F 

X1

G  X 16

# 01 Turn off the computer before installing



# 02



# 03

AEOLUS Box attaches to the computer case via magnet



# 04




**English**
- Fans must start at "1" and continue in series. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Any fan not connected in series will break communication and the RGB lighting fuction will not work.

**Español**
- Los ventiladores deben comenzar en "1" y continuar en serie. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Cualquier ventilador no conectado en serie romperá la comunicación y no se activará la función de iluminación RGB

**Deutsch**
- Lüfter müssen bei „1“ beginnen und in Reihe fortgesetzt werden. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Jeder nicht in Reihe geschaltete Lüfter unterbricht die Kommunikation und die RGB-Beleuchtung funktioniert nicht

**Polski**
- Wentylatory muszą uruchamiać się przy „1” i kontynuować działanie szeregowo. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Wentylator, który nie jest podłączony szeregowo przerwie komunikację i funkcja oświetlenia RGB nie będzie działać

**Français**
- Les ventilateurs doivent commencer à "1" et continuer en série. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Les ventilateurs non connectés en série rompent la communication et empêchant le fonctionnement de l'éclairage RVB

**Svensk**
- Fläktar måste starta på "1" och fortsätta i serie. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Fläkta som inte ansluts i serie kommer att bryta kommunikationen och RGB-belysningsfunktionen kommer inte att fungera

**Italiano**
- Le ventole devono partire da "1" e continuare in serie. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Qualsiasi ventola non collegata in serie interrompe la comunicazione e la funzione di illuminazione RGB non funziona

**Português**
- As ventoinhas devem começar em "1" e continuar em série. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Qualquer ventoinha não conectada em série interromperá a comunicação e a função de iluminação RGB não funcionará

**Русский**
- Вентиляторы запускаются с «1» и далее по порядку. FAN1 → FAN2 → FAN3 → FAN4 → FAN5 → FAN6 → FAN7 → FAN8
- Если какой-либо из вентиляторов не подключен последовательно, связь прерывается, и функция подсветки RGB не работает

**العَرَبِيَّة**

FAN8 ← FAN7 ← FAN6 ← FAN5 ← FAN4 ← FAN3 ← FAN2 ← FAN1→ يجب أن تبدأ المراوح من "1" وتستمر على التوالي.
- إذا لم يتم توصيل أي مروحة على التوالي، فسيتم قطع الاتصال ولن تعمل وظيفة إضاءة RGB

# 05

AEOLUS Box also supports the following liquid cooler

- CHIONE P2-360R
- CHIONE M1A-280R
- CHIONE M1A-240R
- CHIONE E1A-120R
- CHIONE P1A-360R
- CHIONE M2-240R
- CHIONE E2-120R




B







B



⚠ Notice Foolproof design

# 06

If your motherboard has 5V 3-Pin addressable (digital) RGB header, you can customize RGB lighting via motherboard manufacture sync software




















AEOLUS M2-1204R only support 5V addressable (digital) RGB header

# 07 Daisy chain another AEOLUS Box for more lighting effects









# 08


B
D
LED2
FAN5
FAN6
FAN7
FAN8
LED OUT
LED IN
POWER
LED1
FAN1
FAN2
FAN3
FAN4
SATA
PSU


POWER
B
D


SATA
D

# 09 Turn on the computer after installing



C


ON — Turn On Remote Controller

OFF — Turn Off Remote Controller

MB — Motherboard Sync

Mode

Light Speed

Fan Speed

Brightness

AUTO — Lighting Effect

* When press "OFF" button, the remote controller will be automatically disabled. Please press "ON" button to activate.
* Press "MB" button to switch to motherboard sync mode.

# How to change the Battery

C




Bettery type:
**CR2025**

# GAMDIAS

GAMING ART IN MOTION